

REMOTE ANGLED MODBUTTON PLATFORM INSTALLATION INSTRUCTIONS

⚠️ ENSURE FIREARM IS UNLOADED AND SAFE

⚠️ WARNING: DAMAGE CAUSED BY OVER-TORQUED FASTENERS NOT COVERED BY WARRANTY.

1 PRESS FIT HEX NUTS INTO RIGHT SIDE OF MOUNT, THIS PREVENTS NUTS FROM FALLING OUT DURING ASSEMBLY. PLACE RIGHT SIDE OF RAMP IN DESIRED LOCATION ON RAIL.

2 PRESS CABLE INTO HOLE ON THE SIDE INTENDED FOR CABLE TO COME OUT OF. ENSURE CABLE MOVES FREELY INSIDE HOLE. NOW INSERT MODBUTTON LITE BODY INTO RIGHT SIDE OF RAMP MOUNT ENSURING IT IS SEATED CORRECTLY AS SHOWN.

3 PRESS LEFT SIDE OF MOUNT ONTO ASSEMBLY. PUSH BOLTS SUPPLIED WITH ORIGINAL BUTTON THROUGH HOLES ON SIDE OF RAMP MOUNT AND THREAD USING T8 TORX KEY INTO HEX NUTS ON RIGHT SIDE OF MOUNT. USE HAND TIGHT FIT PLUS HALF TURN. DO NOT TORQUE PAST 5 IN-LBS.

4 GAP BETWEEN RIGHT AND LEFT SIDE OF MOUNT SHOULD BE MINIMAL.

5 CONFIRM PLACEMENT OF RAMP DOES NOT INTERFERE WITH BATTERY REPLACEMENT FOR LIGHT OR LASER.

